

AL138 High temp.

Cause analysis

- The filter is blocked, resulting in a small flow
- There is air in the pipe, which causes the water flow to be unsmooth
- The pump is not emptied, resulting in a small flow
- The valve in the water system is not fully opened
- The set temperature is too high and the flow is too small
- The water pump is too small, resulting in a small flow

AL138 High temp.

Solution

- Clean the filter;
- The pipeline is drained, and the automatic exhaust valve is installed at the highest point of the system;
- Water pump discharges the air;
- Open the valve;
- Reduce the set temperature;
- Replace the pump with a larger lift and flow.